



Page: 1 / 25

# **TFT LCD Specification**

Customer:

Model Name: ZE104IA-03A

2019/09/25

Version:

Date:

1.1

Preliminary Specification

**Final Specification** 

#### For Customer's Acceptance

Approved by	Comment



 $\Diamond$ 

Page: 2 / 25

## **Table of Contents**

4
4
5
5
5
7
8
8
8
9
10
10
10
11
12
12
14
14
17
10
18
18
18
18
18 18 18
18 18 18 20
18 18 18 20 20
18 18 20 20 20
18 18 20 20 20 20 22
18 18 20 20 20 22 22
18 18 20 20 20 20 22 22 23
18 18 20 20 20 20 22 22 23 24





Page: 3 / 25

#### **RECORD OF REVISION**

Version	Revise Date	Page	Description
0.1	2019/03/22	All	Preliminary spec for reference.
0.2	2019/05/09	Page4/17	Updated operation & storage temp. and weight
0.3	2019/05/24	Page4/21	Updated thickness & drawing
1.0	2019/08/05	Page4	Updated NTSC, White Point, Response Time and panel power
			consumption
		Page14	Updated Optical Specification
		Page22	Add serial number label information
		Page23	Updated packing weight
1.1	2019/09/25	Page8	Remove I <sub>VDD</sub> minimum
		Page20	Add Lamination precautions





Page: 4 / 25

## 1. FEATURES

ZE104IA-03A is a transmissive type color active matrix liquid crystal display (LCD), which uses amorphous thin film transistor (TFT) as switching devices. This panel has a 10.4 inches diagonally measured active display area with resolution 1024 x 768. This product is composed of a TFT LCD panel, polarizers, driver ICs, FPC and PCBA. Remark : The air-bonding is recommended.

## 2. GENERAL SPECIFICATIONS

ltem	Description	Unit
Display Size	10.4	inch
Display Type	Transmissive, a-Si	-
Active Area (HxV)	210.432 (H) x 157.824 (V)	mm
Number of Dots (HxV)	1024 x RGB x 768	dot
Pixel Pitch(HxV)	0.2055 x 0.2055	mm
Color Arrangement	RGB Stripe	-
Color Numbers	256K/16.7 M	-
Outline Dimension (HxVxT)	220.53 (H) x 168.02 (V) x 1.04 (D)	mm
NTSC (CIE1931) (Under C light)	61.2 (Тур.)	%
White Point (x,y) (Under C light)	х:0.319,у: 0.369(Тур.)	
Response Time	≤35	ms
Viewing Angle (Light On) (R/U/L/D)	CR≧10 @ R/L/U/D(80°/80°/80°/80°) (Min.)	
Surface Treatment	НС	
Contrast Ratio (Light On)	1000:1 (Тур)	
Operation Temperature	-30~80	°C
Storage Temperature	-30~80	°C
Interface	LVDS	
Weight	100 (Тур)	g
Panel power consumption	Max:1.4W @white pattern	W





Page: 5 / 25

## **3. PIN DESCRIPTION**

#### 3.1 Connector

There are 3 connectors on PCBA, location & Pin1 is showed on below figure.



Connectors' type:

- 1. CN1 : Input LVDS CONN, 30pins, P-two , 187098-30091
- 2. CN2: Input BL power CONN,5pins, Cillux,CI4205M2HRD-NH
- 3. CN3: Output BL power CONN, 3pins, Cillux, CI4203M2HRD-NH

#### 3.2 PIN assignment

#### 3.2.1 Connector 1 :

A 30pin connector of P-two 187098-30091 is used for the module electronics interface.

And a special plug needed for connecting this connector, the recommended model is P-two 187130-30xx or JAE FI-X30H.

No	Symbol	I/O	Function	Remark
1	NC		Reserved as BIST function for INX test	1
2	GND	P	Ground	
3	Rin3+	÷	Positive LVDS differential data input (+)	
4	Rin3-	I	Negative LVDS differential data input (-)	
5	GND	Р	Ground	
6	CLK+	I	Clock signal (+)	
7	CLK-	I	Clock signal (-)	
8	GND	Р	Ground	
9	Rin2+	Ι	Positive LVDS differential data input (+)	
10	Rin2-	I	Negative LVDS differential data input (-)	
11	GND	Р	Ground	
12	Rin1+	I	Positive LVDS differential data input (+)	
13	Rin1-		Negative LVDS differential data input (-)	
14	GND	Р	Ground	





Page: 6 / 25

15	Rin0+	I	Positive LVDS differential data input (+)	
16	Rin0-	I	Negative LVDS differential data input (-)	
17	GND	Р	Ground	
18	NC	-	No Connection	
19	GND	Р	Ground	
		I	Selection for 6 bits/8bit LVDS data input	2
20	SEL6/8		Low or NC : 8 bit input mode	
			High : 6 bit input mode	
21	NC	I	Reversed as EE_WP for OTP function	3
22	NC	I	Reversed as EE_SDA for OTP function	3
23	NC	I	Reversed as EE_SCL for OTP function	3
24	Reverse	Ι	Reverse panel function (Display rotation)	4
25	GND	Р	Ground	
26	GND	Р	Ground	
27	GND	Р	Ground	
28	VDD	Р	Power supply: + 3.3V	
29	VDD	Р	Power supply: + 3.3V	
30	VDD	Р	Power supply: + 3.3V	
-				

Note:

- 1. Pin1 is reversed as BIST function for test, don't connect signal to this pin, keep floating.
- 2. SEL6/8 is used for selecting 6bit/8bit LVDS data input, L or NC: 8bit; High:6bit.
- 3. Pin21,22,23 are used as SPI interface for OTP function, don't connect any signal to these pin, and don't short them, keep floating.
- 4. Reverse pin is used for selecting scanning direction.



Fig. 1 Normal scan (Pin24, Reverse = Low or NC)



Fig. 2 Reverse scan (Pin24, Reverse = High)





Page: 7 / 25

#### 3.2.2 Connector 2: Cillux,CI4205M2HRD-NH

5-pin connector is used for input power & control signals for BL converter power IC

No	Symbol	I/O	Function	Remark
1	LED_VCCS	Р	12V input	
2	LED_VCCS	Р	12V input	
3	GND	Р	Ground	
4	LED_PWM	I	PWM	
5		1	Converter power IC Enable	
5	5 LED_EN		(Active High)	

#### 3.2.3 Connector 3: Cillux,CI4203M2HRD-NH

3-pin connector is used for output power to BL module.

No	Symbol	I/O	Function	Remark
1	LED+	Р	Red wire	BL output power
2	LED1-	Р	White wire	BL feedback channel1
3	LED2-	Р	White wire	BL feedback channel2

#### 4. ABSOLUTE MAXIMUM RATING

ltem	Symbol	Min.	Max.	Unit	Remark		
Dower Supply Voltage	VDD	-0.3	3.8	V			
Power Supply Voltage	LED_VCCS	-0.3	25	V			
Storage Temperature	Tstg	-30	+80	°C			
Operating Temperature	Topr	-30	+80	°C			

Note:

- (1) All of the voltages listed above are with respective to GND= 0V
- (2) Device is subject to be damaged permanently if stresses beyond those absolute maximum ratings listed above.



 $\Diamond$ 

Page: 8 / 25

## 5. DC CHARCTERISTICS

#### 5.1 Parameter

literre	Values Symbol				Unit	Remark	
Item	Symbol	Min.	Тур.	Max.	Unit	Remark	
Deuronuelle ne	VDD	3.0	3.3	3.6	V		
Power voltage	LED_VCCS	11	12	13	V		
Input logic high voltage	V <sub>IH</sub>	0.7VDD	-	VDD	V	1	
Input logic low voltage	V <sub>IL</sub>	0	-	0.3VDD	V		
Oursest few Dourse	I <sub>VDD</sub>		385	424	mA	VDD =3.3V@frame 60 Hz, White pattern	
Current for Power	I <sub>LED_VCCS</sub>	-	0.52	6	A	100% PWM Duty @ VLED+ =33V, ILED=80mA*2	
	BL On	3.0		5	V		
LED_EN Control Level	BL Off	0	-	0.3	V		
LED_PWM Control	PWM High Level	3.0	-	5	V		
Level	PWM Low Level	0	-	0.3	V		
LED_PWM Control Frequency	f <sub>РWM</sub>	1K	-	20K	Hz	2	

Note 1: Including signal: SEL6/8 & Reverse

Note 2: LED\_PWM duty >10%.

#### 5.2 LB power output

ltem	Symbol	Values			Unit	Remark
nem	Symbol	Min.	Тур.	Max.	Unit	Remark
Voltage for LED backlight	LED+	31	33	35	V	1
Current for LED backlight	LED1-/LED2-	78	80	82	mA	2

Note 1: output power LED+ OVP is 40V.

Note 2: Set BL feedback 2 channels, each channel feedback current is 80mA





Page: 9 / 25

#### 5.3 Power sequence

The power sequence specifications are shown as the following table and diagram.

Symbol	Va	Unit		
Symbol	Min. Max.		Unit	
t <sub>1</sub>	1	20	ms	
t <sub>2</sub>	1	5	ms	
t <sub>3</sub>	10	50	ms	
t <sub>4</sub>	200	500	ms	
t <sub>5</sub>	200	500	ms	
t <sub>6</sub>	50	200	ms	
t <sub>7</sub>	0	20	ms	
t <sub>8</sub>	500	-	ms	
t <sub>A</sub>	0	50	ms	
t <sub>B</sub>	0	50	ms	



Note 1: Please don't plug the interface cable of on when system is turned on.

Note 2: Please avoid floating state of the interface signal during signal invalid period.

Note 3: It is recommended that the backlight power must be turned on after the power supply for LCD and the interface signal is valid.

Note 4: Control signals include SEL6/8 & Reverse.





Page: 10 / 25

## 6. LVDS SIGNAL TIMING CHARACTERISTICS

#### **6.1AC Electrical characteristics**

Parameter	Symbol	Min	Тур	Мах	Unit s	Condition
Clock frequency	RxFCLK	26.2	51.2	71	MHz	
Input data skew margin	TRSKM	500	500	1/(2*RxFCLK)	ps	Typical value for 1024*600 resolution
Clock high time	TLVCH		4/(7xRxFCLK)		ns	VID =400mv RxVCM=1.2V RxFCLK=71MHz VDD_LVDS=3.3V
Clock low time	TLVCL		3/(7xRxFCLK)	X	ns	
VSD setup time	TenPLL	0	TenPLL	150	us	

#### 6.2 Input clock and data timing diagram







Page: 11 / 25



#### 6.3 DC electrical characteristics

Demonstern	Currence al	Values			l lucit	Demente	
Parameter	Symbol	Min.	Тур.	Max.	Unit	Remark	
LVDS Differential input high Threshold voltage	R <sub>xVTH</sub>	-	-	+100	mV	D -1.0V	
LVDS Differential input low Threshold voltage	R <sub>xVTL</sub>	-100	-	-	mV	R <sub>XVCM</sub> =1.2V	
Input Voltage range (Singled-end)	R <sub>xVIN</sub>	0	-	VDD-1.2+  V <sub>ID</sub>  /2	V		
LVDS Differential input common mode voltage	R <sub>xVCM</sub>	V <sub>ID</sub>  /2	-	VDD-1.2	V		
LVDS Differential voltage	V <sub>ID</sub>	0.2	-	0.6	V		



 $\Diamond$ 

Page: 12 / 25



#### 6.4 data timing

Parameter	Symbol		Unit		
Farameter	Symbol	Min.	Тур.	Max.	onit
DCLK frequency	fclk	52	65	71	MHz
Horizontal display area	thd		1024		DCLK
HSD period	th	1114	1344	1400	DCLK
HSD blanking	thb+thfp	90	320	376	DCLK
Vertical display area	tvd		768		Т <sub>н</sub>
VSD period	tv	778	806	845	T <sub>H</sub>
VSD blanking	tvbp+tvfp	10	38 🛆	(/77)	T <sub>H</sub>

#### 6.5 LVDS data input format







Page: 13 / 25





 $\oslash$ 

Page: 14 / 25

## 7. OPTICAL CHARACTERISTICS

#### 7.1 Optical specification

The relative measurement methods of optical characteristics are shown

Item		Symbol	Condition	Min.	Тур.	Max.	Unit	Note
	Red	Rx			0.645	Typ + 0.02		C Light Source (5) (7),(8)
		Ry			0.334			
Color	Green	Gx			0.284			
Chromaticity (CIE 1931)		Gy		Тур –	0.564			
FOG Only	Blue	Bx		0.02	0.137			
with C-light	Blue	Ву	θ <sub>x</sub> =0°, θ <sub>Y</sub> =0° R=G=B=255		0.121			
with C-light	White	Wx	Gray scale	-	0.319			
		Wy			0.369			
Color gamut		C.G	-	55	61.2	-	%	
Contor Transmittance		Т%		5.4	5.9		%	INX BLU
Center Han	Center Transmittance			J.4	5.9			(1),(4),(6)
Contrast	Contrast Ratio			800	1000	-	-	(2)
Response Time		TR+TF	θ <sub>x</sub> =0°, θ <sub>Y</sub> =0°	-	25	35	ms	(3)
Viewing Angle	Horizontal	x +	CR ≥ 10	80	-	-		
		x -		80	-	-	Deg.	(1),(5)
	Vertical	y +		80	-	-	Dey.	(1),(3)
		у -		80	-	-		

Note (1) Definition of Viewing Angle (\_x, \_y):



Note (2) Definition of Contrast Ratio (CR):

The contrast ratio can be calculated by the following expression.

Contrast Ratio (CR) = L255 / L0

L255: Luminance of gray level 255



www.panelook.com



Page: 15 / 25

L 0: Luminance of gray level 0

CR = CR (5)

CR (X) is corresponding to the Contrast Ratio of the point X at Figure in Note (6).

Note (3) Definition of Response Time :

The response time is defined as the LCD optical switching time interval between "White" state and "Black" state. Rise time (Tr) is the time between photo detector output intensity changed from 10% to 90%. And fall time (Tf) is the time between photo detector output intensity changed from 90% to 10%.

RT = RT (5)

RT (X) is corresponding to the Response Time of the point X at Figure in Note (6).



Note (4) Definition of Luminance of White (Lc):

Measure the luminance of gray level 255 at center point

LC = L(5)

L (x) is corresponding to the luminance of the point X at Figure in Note (6).

Note (5) Measurement Setup:

The LCD module should be stabilized at given temperature for 40 minutes to avoid abrupt

temperature change during measuring. In order to stabilize the luminance, the measurement should be executed after lighting Backlight for 40 minutes in a windless room.





屏库:全球液晶屏交易中心



Page: 16 / 25

Note (6) Definition of White Variation (\_W):

Measure the luminance of gray level 255 at 9 points



- Note (7) The listed optical specifications refer to the initial value of manufacture, but the condition of the specifications after long-term operation will not be warranted.
- Note (8) Definition of color gamut (C.G%):

C.G%= RGB/ R<sub>0</sub>G<sub>0</sub>B<sub>0</sub>,\*100%

- Ro, Go, Bo: color coordinates of red, green, and blue defined by NTSC, respectively.
- R, G, B : color coordinates of module on 255 gray levels of red, green, and blue, respectively.
- $R_0 \, G_0 \, B_0$  : area of triangle defined by  $R_0, \, G_0, \, B_0$ 
  - R G B: area of triangle defined by R, G, B





Ø

Page: 17 / 25

## 8. QUALITY ASSURANCE

No.	Test Items	Test Condition	Note
1	High Temperature Storage	80°C , 240hrs	Note 1, 2
2	Low Temperature Storage	-30℃, 240hrs	Note 1, 2
3	High Temperature Operation	80°C , 240hrs	Note 1, 2
4	Low Temperature Operation	-30 $^\circ\!\mathrm{C}$ , 240hrs	Note 1, 2
5	High Temperature and High Humidity Storage	60℃, 90%RH, 240hrs	Note 1, 2
6	Thermal Shock	-30℃/0.5h ~ +80℃/0.5h for a total 100 cycles	Note 1, 2
7	Electro Static Discharge	C=150pF,R=330Ω, 5point/panel Air:±4Kv, 5times	Note 2
8	Package Drop Test	Drop in 1 corner,3 edges,6 surfaces, 1 time/direction Height follow ISTA(1A) $0kg \le W < 10kg : 76cm,$ $10kg \le W < 19kg : 61cm,$ $19kg \le W < 28kg : 46cm,$ $28kg \le W < 45kg : 31cm,$ $45kg \le W \le 68kg : 20cm$	Note 2

- Note 1: The test samples have recovery time for 2 hours at room temperature before the function check. In the standard conditions, there is no display function NG issue occurred.
- Note 2: After the reliability test, the product only guarantees operation, but don't guarantee all of the cosmetic specification.



Page: 18 / 25

#### **9. PRECAUTIONS**

#### 9.1 ESD (Electrical Static Discharge) strategy

- [1] ESD will cause serious damage of the panel, ESD strategy is very important in handling. Following items are the recommended ESD strategy
- [2] In handling LCD panel, please wear gloves with non-charged material. Using the conduction ring connects wrist to the earth and the conducting shoes to the earth necessary is.
- [3] The machine and working table for the panel should have ESD protection strategy.
- [4] In handling the panel, ionized airflow decreases the charge in the environment is necessary.
- [5] In the process of assemble module, shield case should connect to the ground.

#### 9.2 Environment

- [1] Working environment of the panel should be in the clean room.
- [2] Because touch panel has protective film on the surface, please remove the protection film slowly with ionized air to prevent the electrostatic discharge.

#### 9.3 Assembly and handling precautions

- [1] Do not apply improper or unbalanced force such as bending or twisting to open cells during assembly.
- [2] It is recommended to assemble or to install an open cell into a customer's product in clean working areas. The dust and oil may cause electrical short to an open cell or worsen polarizers on an open cell.
- [3] Do not apply pressure or impulse to an open cell to prevent the damage.
- [4] Always follow the correct power-on sequence when an open cell is assembled and turned on. This can prevent the damage and latch-up of the CMOS LSI chips.
- [5] Do not design sharp-pointed structure / parting line / tooling gate on the plastic part of a COF (Chip on film), because the burr will scrape the COF.
- [6] If COF would be bended in assemble process, do not place IC on the bending corner.
- [7] The gap between COF IC and any structure of BLU must be bigger than 2 mm. This can prevent the damage of COF IC.
- [8] The bezel opening must have no burr and be smooth to prevent the surface of an open cell scraped.
- [9] The bezel of a module or a TV set can not contact with force on the surface of an open cell. It might cause light leakage or scrape.
- [ 10 ] In the case of no FFC or FPC attached with open cells, customers can refer the FFC / FPC drawing and buy them by self.



- [ 11 ] It is important to keep enough clearance between customers' front bezel/backlight and an open cell. Without enough clearance, the unexpected force during module assembly procedure may damage an open cell.
- [ 12 ] Do not plug in or unplug an I/F (interface) connector while an assembled open cell is in operation.
- [ 13 ]Use a soft dry cloth without chemicals for cleaning, because the surface of the polarizer is very soft and easily scratched.
- [ 14 ] Moisture can easily penetrate into an open cell and may cause the damage during operation.
- [ 15 ] When storing open cells as spares for a long time, the following precaution is necessary.
  - [ 15.1 ] Do not leave open cells in high temperature and high humidity for a long time. It is highly recommended to store open cells in the temperature range from 0 to

35°C at normal humidity without condensation.

- [ 15.2 ] Open cells shall be stored in dark place. Do not store open cells in direct sunlight or fluorescent light environment.
- [16] When ambient temperature is lower than 10°C, the display quality might be reduced.
- [17] Unpacking (Cartons/Tray plates) in order to prevent open cells broken:
  - [ 17.1 ] Moving tray plates by one operator may cause tray plates bent which may induce open cells broken. Two operators carry one carton with their two hands. Do not throw cartons/tray plates, avoid any impact on cartons/tray plates, and put down & pile cartons/tray plates gently.
  - [ 17.2 ] A tray plate handled with unbalanced force may cause an open cell damaged. Trays should be completely put on a flat platform.
  - [ 17.3 ] To prevent open cells broken, tray plates should be moved one by one from a plastic bag.
  - [17.4] Please follow the packing design instruction, such as the maximum number of tray stacking to prevent the deformation of tray plates which may cause open cells broken.
  - [ 17.5 ] To prevent an open cell broken or a COF damaged on a tray, please follow the instructions below:
    - [17.5.1] Do not peel a polarizer protection film of an open cell off on a tray
    - [17.5.2] Do not install FFC or LVDS cables of an open cell on a tray

[17.5.3] Do not press the surface of an open cell on a tray.

- [17.5.4] Do not pull X-board when an open cell placed on a tray.
- [ 18 ] Unpacking (Hard Box) in order to prevent open cells broken:
  - [ 18.1 ] Moving hard boxes by one operator may cause hard boxes fell down and open cells broken by abnormal methods. Two operators carry one hard box with



Page: 20 / 25

their two hands. Do handle hard boxes carefully, such as avoiding impact, putting down, and piling up gently.

- [ 18.2 ] To prevent hard boxes sliding from carts and falling down, hard boxes should be placed on a surface with resistance.
- [ 18.3 ] To prevent an open cell broken or a COF damaged in a hard box, please follow the instructions below:

[18.3.1] Do not peel a polarizer protection film of an open cell off in a hard box.

- [18.3.2] Do not install FFC or LVDS cables of an open cell in a hard box.
- [18.3.3] Do not press the surface of an open cell in a hard box.
- [18.3.4] Do not pull X-board when an open cell placed in a hard box.
- [19] Handling In order to prevent open cells, COFs , and components damaged:
  - [ 19.1 ] The forced displacement between open cells and X-board may cause a COF damaged. Use a fixture tool for handling an open cell to avoid X-board vibrating and interfering with other components on a PCBA & a COF.
  - [ 19.2 ] To prevent open cells and COFs damaged by taking out from hard boxes, using vacuum jigs to take out open cells horizontally is recommended.
  - [ 19.3 ] Improper installation procedure may cause COFs of an open cell over bent which causes damages. As installing an open cell on a backlight or a test jig, place the bottom side of the open cell first on the backlight or the test jig and make sure no interference before fitting the open cell into the backlight/the test jig.
  - [19.4] Handle open cells one by one.
- [ 20 ] Avoid any metal or conductive material to contact PCB components, because it could cause electrical damage or defect.

## 9.4 Lamination precautions

[1] Air-Bonding the touch panel or cover is recommended instead of OCA/OCR full lamination.

## 9.5 Safety precautions

- [1] If the liquid crystal material leaks from the open cell, it should be kept away from the eyes or mouth. In case of contact with hands, skin or clothes, it has to be washed away thoroughly with soap.
- [2] After the end of life, open cells are not harmful in case of normal operation and storage.

## 9.6 Others

- [1] Turn off the power supply before connecting and disconnecting signal input cable.
- [2] Because the connection area of FPC and panel is not so strong, do not handle panel only by FPC or bend FPC.

www.panelook.com



Page: 21 / 25

- [3] Water drop on the surface or condensation as panel power on will corrode panel electrode.
- [4] As the packing bag open, watch out the environment of the panel storage. High temperature and high humidity environment is prohibited.
- [5] In the case the TFT LCD module is broken, please watch out whether liquid crystal leaks out or not. If your hand touches liquid crystal, wash your hands cleanly with water and soap as soon as possible.





Page: 22 / 25

10. MECHANICAL DRAWING 10.1 FOG drawing





www.panelook.com

屏库:全球液晶屏交易中心

 $\oslash$ 

Page: 23 / 25

10.2 FOG label serial label explanation





 $\langle \mathcal{P} \rangle$ 

Page: 24 / 25

## **11. PACKING DRAWING**

11.1 Packaging material table

Item	Model (Material)	Dimensions(mm)	Unit Weight (Kg)	Quantity (pcs)	Remark	
FOG module	ZE1014A-03A	220.53x168,02x1.03	0.1	28		
Dust-Proof Bag	LDPE	700 x 530x0.05	0.0595	1		
Tray	Tray, PET	472x360x15.6	0.192	15		
Spacer	EPE	347x217x3.2	0.006	28		
Cushion	EPE	518x356x115	0.0185	2		
Drier	Exsiccator	105 x 80 x 8	0.035	2		
Carton	Corrugated paper	530×367×260	0.95	1		
Total weight	7kg					
	FOG module Dust-Proof Bag Tray Spacer Cushion Drier Carton	FOG moduleZE1014A-03ADust-Proof BagLDPETrayTray, PETSpacerEPECushionEPEDrierExsiccatorCartonCorrugated paper	FOG module ZE1014A-03A 220.53x168,02x1.03   Dust-Proof Bag LDPE 700 x 530x0.05   Tray Tray, PET 472x360x15.6   Spacer EPE 347x217x3.2   Cushion EPE 518x356x115   Drier Exsiccator 105 x 80 x 8   Carton Corrugated paper 530×367×260	FOG module ZE1014A-03A 220.53x168,02x1.03 0.1   Dust-Proof Bag LDPE 700 x 530x0.05 0.0595   Tray Tray, PET 472x360x15.6 0.192   Spacer EPE 347x217x3.2 0.006   Cushion EPE 518x356x115 0.0185   Drier Exsiccator 105 x 80 x 8 0.035   Carton Corrugated paper 530×367×260 0.95	FOG module ZE1014A-03A 220.53x168,02x1.03 0.1 28   Dust-Proof Bag LDPE 700 x 530x0.05 0.0595 1   Tray Tray, PET 472x360x15.6 0.192 15   Spacer EPE 347x217x3.2 0.006 28   Cushion EPE 518x356x115 0.0185 2   Drier Exsiccator 105 x 80 x 8 0.035 2   Carton Corrugated paper 530×367×260 0.95 1	

#### **11.2 Packaging quantity**

Total Panel quantity of per Carton: 2pcs/ tray x 14 (15-1) tray / Carton = 28 pcs



 $\oslash$ 

#### 11.3 Packaging drawing

